

# INSECT GUARD MOSQUITO REPELLER

**TECHNICAL SHEET** 



# **INSECT GUARD MOSQUITO REPELLER**

#### **Benefits**

- Night and day protection from mosquitoes
- Lasts up to 40 nights\*
- Protects a room of up to 30 m³
- Adjustable timer (9 and 24 hours)
- Low dour
- Easy to use

#### Controls

Mosquitoes plus House Flies, Blow Flies, Fruit Flies, Midges, Moths, and more.





# Directions

#### To activate the device and start protection from Mosquitoes:

- 1. Unscrew the cap of the liquid refill and retain the cap.
- 2. Place the refill into the plug-in unit, keeping both the unit and the refill upright. Avoid touching wick.
- 3. Insert refill into the plug-in unit and turn to the right to secure the refill in the unit.
- 4. Always keep the plug-in unit and refill upright.
- 5. Plug the assembled unit into an electrical power outlet and switch on at the wall.

#### To enter Day/Night Mode (24-hour):

- 1. Once the unit is plugged in, press the 'On-Off/Set' button once. A red light will appear next to 'Work'.
- 2. The unit will stay on continuously for 24 hours. To enter Night Mode (9-hour):
- 3. To put the unit into Night Mode, push the 'On-Off/Set' button for a second time. This will keep the unit on for 9 hours. It will then switch itself off automatically for 15 hours.
- 4. After 15 hours the unit will switch back on for the 9-hour period and so forth. Simultaneous green and red lights indicate the unit is ON.
- 5. The red light will go out after 9 hours, and the unit will enter the 15-hour delay.

#### To turn off:

- 1. To turn the unit off, keep pushing the 'On-Off/Set' button until both the red and green lights switch off.
- 2. Alternatively switch off at power.
- 3. Once the refill is empty, the unit will switch itself off. Replace the refill as indicated in the steps above.
- 4. When not in use, remove the appliance from the power outlet. Retain the refill cap and screw on when not in use.

<sup>\*</sup>When used in 9-hour mode. The level of liquid can be seen easily.

### Caution

- Use in a well-ventilated area.
- Do not touch the refill while the heater is plugged in. Do not touch the heater with metal instruments or wet hands. Do not introduce any objects in the heater nor cover it while in use.
- Only to be used with compatible refills.
- Unplug when the bottle is empty, only replace the bottle when the device is unplugged.
- This appliance is not intended for use by young children or people with reduced physical, sensory or mental capabilities. Young children should be supervised to ensure that they do not play with the appliance.

# **Active Ingredients**

• 12 g/L Prallethrin

#### Available As

• Plug-In Unit & 45 ml Refill/s

# **Complimentary Products**

- Insect Guard Automatic Range
- Insect Guard Surface Spray Range

## **FAQs**

#### Q. What is Prallethrin?

- A. Prallethrin is a safe pyrethroid insecticides that, because it is volatile, readily transitions to the vapour phase to stay in the air longer and penetrate the treatment space. It is easily contacted and 'breathed in' by the pest insects giving effective rapid control.
- Q. How long does INSECT GUARD Mosquito Repeller take to work?
- A. Typically, with INSECT GUARD Mosquito Repeller takes 1-2 hours to be fully effective.
- Q. Can INSECT GUARD Mosquito Repeller be left on when going on holiday?
- A. We advise switching the units off when the home is not going to be occupied for more than a few days. You could, of course, take the unit with you on holiday, ensuring the refill has its lid tightly on.



FOR MORE INFORMATION: CONTACT YOUR LOCAL KIWICARE TERRITORY MANAGER,
VISIT
WWW.KIWICARE.CO.NZ/INSECTGUARD
OR PHONE 033890778